APPLICATIONS FOR THE PIAB CRANEWEIGHER

The Institute of Technology in Stockholm, Metal Working Department, uses a 22000 lb. (10000 kg) PIAB Craneweigher to measure weights and to ensure that the overhead crane is not being overloaded.





In this shipyard they use a 110000 lb. (50000 kg) PIAB Craneweigher for weighing ship sections and for testing anchor windlass and winches.



When making lifting gear (ropes, slings, hooks, shackles, etc.) a tension testing machine is used fitted with a 110000 lb. (50000 kg) capacity PIAB Craneweigher. This testing machine is used for proof loading and for testing to destruction. The latter is facilitated by the non-return pointer which indicates the max. loading reached.







CRANEWEIGHER



For weighing and force measurement where the demands for accuracy, reliability and safety are high. The PIAB Craneweigher is constructed for continuous service under the most severe conditions.



RANGE OF APPLICATION

instrument, equally suitable for use in or out of doors and may be supplied with or without remote-reading instruments for weighing and for measuring of mechanical forces.

The PIAB Craneweigher is an all-weather
The PIAB Craneweigher is exceptionally well suited for measurements in breaking tests, as the max. load pointer remains at the breaking point or max. value reached.

FUNCTION

The pull rod operates the pointer through a spring loaded floating transmission mechanism. This allows the craneweigher to withstand very severe shock loads and rapid unloading.

The power-absorbing element consists of specially made Belleville type spring washers, so designed as to be entirely free from wear.

The spring washers cannot be overloaded.

SAFETY

Safety factor 5:1. (Guaranteed to withstand a load of 5 times full scale reading before rupture.) The resistance to rupture is tested by the National Swedish Institute for Materials Testing.

The craneweigher may be overloaded by 100% without impairing the accuracy. The scale is protected by thick acrylic glass and a heavy duty removable wire shield. The craneweighers, types WA-WG have drop-forged steel eye brackets (SIS 2174 St 52-3N acc. to DIN 17100, 50 D acc. to BS 4360); giving a guaranteed

impact resistance to -4°F (-20°C).

The O-ring of the pull rod is protected by a neoprene rubber membrane.

On instantaneous unloading, e.g. breaking test, the return movement of the pull rod is retarded by a specially made spring washer.

The PIAB Craneweigher is approved by the National Swedish Board of Occupational Safety and Health for integral connection in the carrying system of a lifting device and for weighing of test loads in connection with inspection.

PROTECTION AGAINST CORROSION

The PIAB Craneweigher is fully pressure tight and each instrument is pressure tested. No leakage is permitted. The external surfaces are zinc plated

with clear chromate passivation. If the craneweigher is to be used in a very corrosive atmosphere, it can be epoxylacquered.

CRANEWEIGHER FOR REMOTE READING

The PIAB Craneweigher used for remote reading is supplied with a builtin precision potentiometer. The potentiometer is directly connected to the scale mechanism of the PIAB instrument. The electrical resistance of the potentiometer varies in proportion to the load of the craneweigher. The resistance is indicated on a recei-

ving instrument, calibrated individually

and marked with the same serial number as the craneweigher. The electrical connections are made in the terminal box to a numbered connection block.


A craneweigher with potentiometer cannot be equipped with max. pointer. If a craneweigher with potentiometer is delivered without receiving instrument, a resistance chart with at least 10 incremental values is included.

CRANEWEIGHER WITH CONTACT FUNCTION

The PIAB Craneweigher can be equipped with a built-on adjustable contact head. Using a microswitch, which is directly influenced by the pull rod, the craneweigher gives an electrical contact function at a previously set value. The contact head is built-on as an extension of the craneweigher. For the types WA-WO the extension is about 3.15/16" (100 mm), for WQ about 4.1/3" (110 mm), for WS about 3.5/64" (78 mm) and for the types WU-WE about 3.35/64" (95 mm).

The Craneweighers types WA-WO can be equipped with up to two microswitches and types WQ-WE with up to five microswitches.

The electrical connections are made in the terminal box to a numbered connection block.



ART.NO.	TYPE	CAPACITY	GRADUATION	DEAD	MEASUREMENTS IN INCHES AND (MM)								
				WEIGHT	Α	В	С	D	E	F	G	Н	I
300420 300421 300422	WA NWA WC	500 kg 5 kN 1100 lb.	5 kg 50 N 10 lb.										
300425 300426 300427	WB NWB WD	1000 kg 10 kN 2200 lb.	10 kg 100 N 20 lb.	35 lb.	15.9/16	12.7/8	9.7/32	1.49/64	1.11/32	1.57/64	63/64	3.25/64	1.19/64
300430 300431 300432	WM NWM WN	2000 kg 20 kN 4400 lb.	20 kg 200 N 50 lb.	(16 kg)	(395)	(327)	(234)	(45)	(34)	(48)	(25)	(86)	(33)
300435 300436 300437	WP	3000 kg 30 kN 6600 lb.	20 kg 200 N 50 lb.										
300440 300441	WQ	5000 kg 50 kN	50 kg 500 N	53 lb.	16.1/4	12.15/16	9.1/16	1.49/64	1.21/32	2.11/64	1.3/16	4.51/64	1.37/64
300441	WŘ	11000 lb.	100 lb.	(24 kg)	(413)	(329)	(230)	(45)	(42)	(55)	(30)	(122)	(40)
300445 300446 300447	WS NWS WT	10000 kg 100 kN 22000 lb.	100 kg 1 kN 200 lb.	79 lb. (36 kg)	19.1/2 (495)	15.5/32 (385)	10.15/64 (260)	2.23/64 (60)	2.11/64 (55)	2.9/16 (65)	1.49/64 (45)	5.55/64 (149)	2.13/64 (56)
300450 300451 300452	WU NWU WV	20000 kg 200 N 44000 lb.	200 kg 2 kN 500 lb.	196 lb.	26.37/64	19.7/8	11.13/16	4.1/64	3.11/32	4.1/16	2.3/4	8.31/32	3.3/16
300455 300456 300457		25000 kg 250 kN 55000 lb.	200 kg 2 kN 500 lb.	(89 kg)	(675)	(505)	(300)	(102)	(85)	(103)	(70)	(228)	(81)
300460 300461 300462	WE NWE WF	50000 kg 500 kN 110000 lb.	500 kg 5 kN 1000 lb.	278 lb. (126 kg)	32.23/32 (831)	24.27/32 (631)	15.15/64 (387)	4.27/32 (123)	3.15/16 (100)	4.49/64 (121)	3.47/64 (95)	9.7/32 (234)	4.17/32 (115)

The pull rod movement at full load is approximately 25/64". We reserve the right to change without notice.



ACCURACY

 $\pm 0.5\%$ of the max. capacity.

WORKING TEMPERATURE

Max. 140°F (+60°C). If the craneweigher is used above objects emitting strong radiant heat, e.g. in foundries, it should be equipped with the heat radiation shield and machine glass. Machine glass cannot be equipped with max. pointer.

TAREING

The craneweigher can be tared to approx. 10% of the full scale. To obtain the best accuracy, the craneweigher should be supplied calibrated for a known tare.

Ø 11.15/64" inclined 20° to facilitate reading from below. The scale is white lacquered with black graduation. It is also available with intermediate graduation.

MAX. DEFLECTION Approx. 330°.

The craneweigher can be graduated in kg, kp, N, lb, cwt., etc.



PIAB Force Measurement is certificated according to SS-ISO 9001.